



DIRECT+
Conditioning System



ENVOY



AUTHORITY22[®]

Select Machine

Pattern Information

Date: 17-joulu-23
 Pattern Type:
 Pattern Difficulty:
 Pattern Designer: jkl
 Pattern Volume (ml): 22,02

Surface Information

Surface Type: Synthetic
 Surface Brand: Brunswick Pro Lane
 Age: 16

Pattern Parameters

Pattern Number:
 Pattern Name: Unelma 2024
 Mode: Clean & Oil
 Forward Speed: Quick Clean
 Start Cleaner Spray: 0
 Start Squeegee: 0
 Start Oiling: 6
 Split Pattern:


Supplies Information

Lane Cleaner: Judge
 Cleaner Mixture Ratio: 6 : 1
 Cleaner Transition Distance: Authority22
 Cleaner Spray End Distance: 52 Envoy
 Lane Conditioner: hp209hv

Notes: _____

	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5	Zone 6	Zone 7	Zone 8
Zone End Distance	10	18	26	32	42			
Zone Ratio	L: 3,7 : 1	3,6 : 1	3,6 : 1	### : 1	### : 1	### : 1	### : 1	### : 1
	R: 3,7 : 1	3,6 : 1	3,6 : 1	### : 1	### : 1	### : 1	### : 1	### : 1
Zone Volume (ml)	9,01	6,39	4,91	1,71	0,00	0,00	0,00	0,00

ZONE	7 Pin Side																	Board Number												10 Pin Side											
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1		
1	0	22	22	22	22	25	30	38	45	55	63	68	80	88	90	90	90	90	90	90	90	90	90	90	88	80	68	63	55	45	38	30	25	22	22	22	22	0			
2	0	20	20	20	20	23	26	35	40	48	55	58	70	78	80	80	80	80	80	80	80	80	80	80	80	78	70	58	55	48	40	35	26	23	20	20	20	20	0		
3	0	15	15	15	15	18	20	27	33	38	45	48	55	58	60	60	60	60	60	60	60	60	60	60	58	55	48	45	38	33	27	20	18	15	15	15	15	0			
4	0	0	0	0	0	0	0	7	10	15	20	32	36	40	40	40	40	40	40	40	40	40	40	40	36	32	20	15	10	7	0	0	0	0	0	0	0	0	0		
5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
6																																									
7																																									
8																																									





Unelma 2024

Crosswise Ratios (by units)

Zone 1			Zone 5		
	Average	Ratio		Average	Ratio
3L-7L	Left = 24,2	3,7	3L-7L	Left = 0,0	#JAKO/0!
3R-7R	Right = 24,2	3,7	3R-7R	Right = 0,0	#JAKO/0!
18L-18R	Center = 90,0		18L-18R	Center = 0,0	
Zone 2			Zone 6		
	Average	Ratio		Average	Ratio
3L-7L	Left = 21,8	3,6	3L-7L	Left = #JAKO/0!	#JAKO/0!
3R-7R	Right = 21,8	3,6	3R-7R	Right = #JAKO/0!	#JAKO/0!
18L-18R	Center = 80,0		18L-18R	Center = #JAKO/0!	
Zone 3			Zone 7		
	Average	Ratio		Average	Ratio
3L-7L	Left = 16,6	3,6	3L-7L	Left = #JAKO/0!	#JAKO/0!
3R-7R	Right = 16,6	3,6	3R-7R	Right = #JAKO/0!	#JAKO/0!
18L-18R	Center = 60,0		18L-18R	Center = #JAKO/0!	
Zone 4			Zone 8		
	Average	Ratio		Average	Ratio
3L-7L	Left = 0,0	#JAKO/0!	3L-7L	Left = #JAKO/0!	#JAKO/0!
3R-7R	Right = 0,0	#JAKO/0!	3R-7R	Right = #JAKO/0!	#JAKO/0!
18L-18R	Center = 40,0		18L-18R	Center = #JAKO/0!	

Crosswise Ratios (by ml)

Zone 1			Zone 5		
	Average	Ratio		Average	Ratio
3L-7L	Left = 0,101	3,7	3L-7L	Left = 0,000	#JAKO/0!
3R-7R	Right = 0,101	3,7	3R-7R	Right = 0,000	#JAKO/0!
18L-18R	Center = 0,377		18L-18R	Center = 0,000	
Zone 2			Zone 6		
	Average	Ratio		Average	Ratio
3L-7L	Left = 0,073	3,6	3L-7L	Left = 0,000	#JAKO/0!
3R-7R	Right = 0,073	3,6	3R-7R	Right = 0,000	#JAKO/0!
18L-18R	Center = 0,268		18L-18R	Center = 0,000	
Zone 3			Zone 7		
	Average	Ratio		Average	Ratio
3L-7L	Left = 0,056	3,6	3L-7L	Left = 0,000	#JAKO/0!
3R-7R	Right = 0,056	3,6	3R-7R	Right = 0,000	#JAKO/0!
18L-18R	Center = 0,201		18L-18R	Center = 0,000	
Zone 4			Zone 8		
	Average	Ratio		Average	Ratio
3L-7L	Left = 0,000	#JAKO/0!	3L-7L	Left = 0,000	#JAKO/0!
3R-7R	Right = 0,000	#JAKO/0!	3R-7R	Right = 0,000	#JAKO/0!
18L-18R	Center = 0,101		18L-18R	Center = 0,000	

The crosswise ratios are calculated by the average units of oil for boards 18L - 18R and divided by the average units of oil for board 3 - 7 left and right.

